

# MEASUREMENT

## BOTTOMS

NORMAL TROUSER LENGTH – leg length 82 cm																	
Waist measurement cm	72	76	80	84	88	92	96	100	104	108	112	116	120	124	128	132	136
DE - NL*	42	44	46	48	50	52	54	56	58	60	62	64	66	68	70	72	74
DE - NL**	36	40	44	46	48	50	52	54	56	56A	58	58A	60	62	64	66	68
DE - NL***	36	40	44	46	48	50	52	54	56	58	60	62	64	66	68	70	72
B - P - CH - ES - FR	36	38	40	42	44	46	48	50	52	54	56	58	60	62	64	66	68
UK	28,5"	30"	31,5"	33"	34,5"	36"	38"	39,5"	41"	42,5"	44"	45,5"	47"	49"	50,5"	52"	53,5"

\* Galaxy, Combat, X-treme, Cargo, Enterprise Stretch, Safety

\*\* Standard, Enterprise

\*\*\* Light, Safety+

EXTRA LEG LENGTH – leg length 88-92 cm							
Waist measurement cm	80	84	88	92	96	100	104
DE - NL	90	94	98	102	106	110	114
B - P - CH - ES - FR	40L	42L	44L	46L	48L	50L	52L
UK	L31,5"	L33"	L34,5"	L36"	L38"	L39,5"	L41"

SHORTER LEG LENGTH – leg length 76-77 cm							
Waist measurement cm	80	84	88	92	96	100	104
DE - NL	22	23	24	25	26	27	28
B - P - CH - ES - FR	40C	42C	44C	46C	48C	50C	52C
UK	S31,5"	S33"	S34,5"	S36"	S38"	S39,5"	S41"

## TOPS

SIZES										
Chest measurement cm	88	94	100	106	112	118	124	130	136	142
Int. sizes	XS	S	M	L	XL	2XL	3XL	4XL	5XL	6XL
Neck width	35/36	37/38	39/40	41/42	43/44	45/46	47/48	49/50	51/52	53/54

## TO MEASURE YOUR SIZE CORRECTLY:

Get someone to help you. If you do, you'll get a more exact reading. Keep your shirt and trousers on and stand in a relaxed position. Let your arms hang loosely by your sides. Draw the tape measure horizontally around your body. It should lie close into the body, but should not be too tight.

- A** Measure around neck (measure tightly + 2 cm)
- B** Measure around the chest with arms flat along side of body
- C** Measure around body where waistband is to be placed
- D** Measure from crotch to floor inside at leg (without shoes)

